

AUDIO DOORPHONE

DP-2KN


Audio Doorphone

- Audio Doorphone
- Door Release Button
- Door Latch Connected & Powered from the Door Unit
- 2 Wire between Handset & Door Unit
- Input Power 12V DC Regulated
- Xylophone chime with volume control
- 98mm(W)/ 214mm(H)/ 60mm(D)
- Matching Door Station: DR2GR/ DR201AS/ DR2KS/ DR20SD



DP2KN

SYSTEM DIAGRAM



DPRA - 01M/ 01SD


Audio Doorphone

- Audio Doorphone, 2 Handsets
- Door Release Button
- Talk between Room units
- 2 Wires from Master Handset to Door Unit
- 2 Wires from Handsets to Door Latch
- 5 Wires between Master and Slave Handsets
- Input Power 12V DC Regulated
- Xylophone chime with volume control
- 88mm(W)/ 230mm(H)/ 70mm(D)
- Matching Door Station: DR2G/ DR201A/ DR2K/ DR20S



DPRA01M/ DPRA01SD

SYSTEM DIAGRAM




DOOR STATION




DR2G(R)
Aluminum
Surface Mount



DR201A(S)
Aluminum
Flush Mount



DR2K(S)
Plastic
Surface Mount



DR20S(D)
Aluminium
Surface Mount